INFINITI V10.11 Diagnostics List(Note:For reference only)

ILLUSTRATION: **S**:Sys. Info. **C**:DTC--Read code & Clear code **D**:Data Stream **T**:Action Test **F**:Special Functions(F1、F2、F3……)
F1:Function test(*) F2:Work Support(*) F3:Freeze Frame(*) F4:IDLE AIR VOL LEARN(*) F5:Calib Data (*) F6:Can Diag(*) F7:Can Diag Support Mntr (*) F8:DTC&SRT CONFIRMATION

HLL:HEAD LAMP LEVELIZER , LDW:LANE CAMERA , AFS:ADAPTIVE LIGHT , NATS:NATS IMMU , SE:SMART ENTRANCE , AIRL:AIR LEVELIZER , RCM:REARVIEW CAMERA , SCM:S/BLIND CAMERA , AEM:ACTIVE ENG MOUNT , AS:ACTIVE SUS , ASCD:Auto Speed Controlo Device , CGC:CHG COMM , TETC:TK_ECU_TYPE_CLUCH , DC:DISTANCE CONTROL , MA:MOTOR ASSIST , IVMS:Integrated Voice-Messaging System , TQC:TORQ CONT , AP:ACCELE PEDAL , CON:CONVERTIBLE ROOF

Vehicle	Vehicle Type	Release Date	Eng	AT	ABS	BCM	IPC	ABG	ICC	HVAC	ITM	EPS	IPDM	APM	HLL	E-4WD	I-KEY	DIU	ASD	PSB	ADP	4WD	4WAS /RAS /HICAS	SONAR	LDW	NATS	SE	AIRL	RCM	SCM	AS	MA	IVMS	TCS	AP	ABD	CON	E-SUS	LAS	Break Cont	AUTO SLID	CANGAT EWA	POPUP HOO	TOTAL ILLU	OCCUPANT	MULTI DISP	SVT
INFINITI EX35	J50	2007 2008 2009 2010 2011	SCD	SCD	SCD	SCD	SCD	SCD	SCD		SCD		SCD		SCD					SCD	SCD	SCD		CD	SCD				SD						SCD					SCD							
INFINITI FX35/FX45	S50	2003 2004 2005 2006 2007 2008	SCD	SCD	SCD	SCD	CD	SC	SCD	SCD	SCD	SCD	SCD	SCD	SCD	SCD	SCD	CD	SCD	SCD	SCD	SCD	SCD	CD	SCD	SC	CD	CD	SD	SD	SCD	CD	SCD	SCD						SCD							
INFINITI FX35/FX50	S51	2008 2009 2010 2011	SCD	SCD	SCD	SCD	SCD	SCD	SCD		SCD		SCD	SCD	SCD					SCD	SCD	SCD	SCD	CD	SCD				SD						SCD			SCD		SCD		SCD					
INFINITI G20	P11	1999 2000 2001 2002	SCD	SCD	SCD	SCD	CD	SC	SCD	SCD	SCD	SCD	SCD	SCD	SCD	SCD	SCD	CD	SCD	SCD	SCD	SCD	SCD	CD	SCD	SC	CD	CD	SD	SD	SCD	CD	SCD	SCD						SCD							
INFINITI G25/G37 Sedan	V36	2009 2010 2011	SCD	SCD	SCD	SCD	SCD	SCD	SCD		SCD		SCD		SCD					SCD	SCD	SCD	SCD	CD													SCD			SCD							
INFINITI G35 Coupe	CV35	2003 2004 2005 2006 2007	SCD	SCD	SCD	SCD	CD	SC	SCD	SCD	SCD	SCD	SCD	SCD	SCD	SCD	SCD	CD	SCD	SCD	SCD	SCD	SCD	CD	SCD	SC	CD	CD	SD	SD	SCD	CD	SCD	SCD						SCD							
INFINITI G35 Sedan	V36	2006 2007 2008	SCD		SCD	SCD	SCD	SCD	SCD		SCD		SCD		SCD					SCD	SCD	SCD	SCD	CD					SD											SCD							
INFINITI G35 Sedan	V35	2003 2004 2005 2006	SCD	SCD	SCD	SCD	CD	SC	SCD	SCD	SCD	SCD	SCD	SCD	SCD	SCD	SCD	CD	SCD	SCD	SCD	SCD	SCD	CD	SCD	SC	CD	CD	SD	SD	SCD	CD	SCD	SCD						SCD							
INFINITI G37 Convertible	HV36	2009 2010 2011	SCD	SCD	SCD	SCD	SCD	SCD	SCD		SCD		SCD		SCD					SCD	SCD	SCD	SCD	CD													SCD			SCD							

INFINITI V10.11 Diagnostics List(Note:For reference only)

ILLUSTRATION: **S**:Sys. Info. **C**:DTC--Read code & Clear code **D**:Data Stream **T**:Action Test **F**:Special Functions(F1、F2、F3……)
F1:Function test(*) F2:Work Support(*) F3:Freeze Frame(*) F4:IDLE AIR VOL LEARN(*) F5:Calib Data (*) F6:Can Diag(*) F7:Can Diag Support Mntr (*) F8:DTC&SRT CONFIRMATION

HLL:HEAD LAMP LEVELIZER , LDW:LANE CAMERA , AFS:ADAPTIVE LIGHT , NATS:NATS IMMU , SE:SMART ENTRANCE , AIRL:AIR LEVELIZER , RCM:REARVIEW CAMERA , SCM:S/BLIND CAMERA , AEM:ACTIVE ENG MOUNT , AS:ACTIVE SUS , ASCD:Auto Speed Controlo Device , CGC:CHG COMM , TETC:TK_ECU_TYPE_CLUCH , DC:DISTANCE CONTROL , MA:MOTOR ASSIST , IVMS:Integrated Voice-Messaging System , TQC:TORQ CONT , AP:ACCELE PEDAL , CON:CONVERTIBLE ROOF

Vehicle	Vehicle Type	Release Date	Eng	AT	ABS	BCM	IPC	ABG	ICC	HVAC	ITM	EPS	IPDM	APM	HLL	E-4WD	I-KEY	DIU	ASD	PSB	ADP	4WD	4WAS /RAS /HICAS	SONAR	LDW	NATS	SE	AIRL	RCM	SCM	AS	MA	IVMS	TCS	AP	ABD	CON	E-SUS	LAS	Break Cont	AUTO SLID	CAN GAT EWA	POP UP HOO	TOTAL ILLU	OCC UPANT	MULTI DISP	SVT
INFINITI G37 Coupe	CV36	2007 2008 2009 2010 2011	SCD	SCD	SCD	SCD	SCD	SCD	SCD		SCD		SCD		SCD					SCD	SCD	SCD	SCD	CD																SCD							
INFINITI G37 Sedan	V36	2008 2009 2010	SCD	SCD	SCD	SCD	SCD	SCD	SCD		SCD		SCD		SCD					SCD	SCD	SCD	SCD	CD													SCD			SCD							
INFINITI I30	CA32	1996 1997 1998 1999 2000 2001	SCD	SCD	SCD	SCD	CD	SC	SCD	SCD	SCD	SCD	SCD	SCD	SCD	SCD	SCD	CD	SCD	SCD	SCD	SCD	SCD	CD	SCD	SC	CD	CD	SD	SD	SCD	CD	SCD	SCD						SCD							
INFINITI I35	CA33	2002 2003 2004	SCD	SCD	SCD	SCD	CD	SC	SCD	SCD	SCD	SCD	SCD	SCD	SCD	SCD	SCD	CD	SCD	SCD	SCD	SCD	SCD	CD	SCD	SC	CD	CD	SD	SD	SCD	CD	SCD	SCD						SCD							
INFINITI M35/M45	Y50	2005 2006 2007 2008 2009 2010	SCD	SCD	SCD	SCD	CD	SC	SCD		SCD		SCD	SCD			SCD			SCD	SCD	SCD	SCD	CD	SCD				SD											SCD							
INFINITI M37/M56	Y51	2010 2011	SCD	SCD	SCD	SCD	CD	SCD	SCD	SCD	SCD		SCD	SCD	SCD					SCD	SCD	SCD	SCD	CD										SCD		SCD	SCD		SCD		SCD					
INFINITI M45	Y34	2003 2004 2005	SCD	SCD	SCD	SCD	CD	SC	SCD	SCD	SCD	SCD	SCD	SCD	SCD	SCD	SCD	CD	SCD	SCD	SCD	SCD	SCD	CD	SCD	SC	CD	CD	SD	SD	SCD	CD	SCD	SCD						SCD							
INFINITI Q45	FY33	1995 1996 1997 1998 1999 2000 2001	SCD	SCD	SCD	SCD	CD	SC	SCD	SCD	SCD	SCD	SCD	SCD	SCD	SCD	SCD	CD	SCD	SCD	SCD	SCD	SCD	CD	SCD	SC	CD	CD	SD	SD	SCD	CD	SCD	SCD						SCD							

INFINITI V10.11 Diagnostics List(Note:For reference only)

ILLUSTRATION: **S**:Sys. Info. **C**:DTC--Read code & Clear code **D**:Data Stream **T**:Action Test **F**:Special Functions(F1、F2、F3……)
F1:Function test(*) F2:Work Support(*) F3:Freeze Frame(*) F4:IDLE AIR VOL LEARN(*) F5:Calib Data (*) F6:Can Diag(*) F7:Can Diag Support Mntr (*) F8:DTC&SRT CONFIRMATION

HLL:HEAD LAMP LEVELIZER , LDW:LANE CAMERA , AFS:ADAPTIVE LIGHT , NATS:NATS IMMU , SE:SMART ENTRANCE , AIRL:AIR LEVELIZER , RCM:REARVIEW CAMERA , SCM:S/BLIND CAMERA , AEM:ACTIVE ENG MOUNT , AS:ACTIVE SUS , ASCD:Auto Speed Controlo Device , CGC:CHG COMM , TETC:TK_ECU_TYPE_CLUCH , DC:DISTANCE CONTROL , MA:MOTOR ASSIST , IVMS:Integrated Voice-Messaging System , TQC:TORQ CONT , AP:ACCELE PEDAL , CON:CONVERTIBLE ROOF

Vehicle	Vehicle Type	Release Date	Eng	AT	ABS	BCM	IPC	ABG	ICC	HVAC	ITM	EPS	IPDM	APM	HLL	E-4WD	I-KEY	DIU	ASD	PSB	ADP	4WD	4WAS /RAS /HICAS	SONAR	LDW	NATS	SE	AIRL	RCM	SCM	AS	MA	IVMS	TCS	AP	ABD	CON	E-SUS	LAS	Break Cont	AUTO SLID	CANGATEWA	POPUP HOO	TOTAL ILLU	OCCUPANT	MULTI DISP	SVT
INFINITI Q45	F50	2001 2002 2003 2004 2005 2006*	SCD	SCD	SCD	SCD	CD	SC	SCD	SCD	SCD	SCD	SCD	SCD	SCD	SCD	SCD	CD	SCD	SCD	SCD	SCD	SCD	CD	SCD	SC	CD	CD	SD	SD	SCD	CD	SCD	SCD						SCD							
INFINITI QX4	JR50	1997 1998 1999 2000 2001 2002 2003	SCD	SCD	SCD	SCD	CD	SC	SCD	SCD	SCD	SCD	SCD	SCD	SCD	SCD	SCD	CD	SCD	SCD	SCD	SCD	SCD	CD	SCD	SC	CD	CD	SD	SD	SCD	CD	SCD	SCD						SCD							
INFINITI QX56	Z62	2010 2011	SCD	SCD	SCD	SCD	CD	SCD	SCD	SCD	SCD		SCD	SCD	SCD					SCD	SCD			CD					SD					SCD	SCD				SCD		SCD					
INFINITI QX56	JA60	2004 2005 2006 2007 2008 2009 2010	SCD	SCD	SCD	SCD	CD	SC	SCD	SCD	SCD	SCD	SCD	SCD	SCD	SCD	SCD	CD	SCD	SCD	SCD	SCD	SCD	CD	SCD	SC	CD	CD	SD	SD	SCD	CD	SCD	SCD						SCD							
INFINITI EX35/EX30d	J50	2009 2010 2011	SCD	SCD	SCD	SCD	SCD	SCD	SCD		SCD		SCD		SCD					SCD	SCD	SCD		CD	SCD										SCD					SCD							
INFINITI EX37	J50	2008 2009	SCD	SCD	SCD	SCD	SCD	SC	SCD		SCD		SCD	SCD	SCD						SCD	SCD		CD					SD											SCD							
INFINITI FX37/FX50	S51	2008 2009	SCD	SCD	SCD	SCD	SCD	SC	SCD		SCD		SCD	SCD	SCD						SCD	SCD	SCD	CD														SCD		SCD							
INFINITI FX37/FX50/FX30d	S51	2009 2010	SCD	SCD	SCD	SCD	SCD	SCD	SCD		SCD		SCD	SCD	SCD					SCD	SCD	SCD	SCD	CD	SCD				SD									SCD		SCD		SCD					

INFINITI V10.11 Diagnostics List(Note:For reference only)

ILLUSTRATION: **S**:Sys. Info. **C**:DTC--Read code & Clear code **D**:Data Stream **T**:Action Test **F**:Special Functions(F1、F2、F3……)
F1:Function test(*) F2:Work Support(*) F3:Freeze Frame(*) F4:IDLE AIR VOL LEARN(*) F5:Calib Data (*) F6:Can Diag(*) F7:Can Diag Support Mntr (*) F8:DTC&SRT CONFIRMATION

HLL:HEAD LAMP LEVELIZER , LDW:LANE CAMERA , AFS:ADAPTIVE LIGHT , NATS:NATS IMMU , SE:SMART ENTRANCE , AIRL:AIR LEVELIZER , RCM:REARVIEW CAMERA , SCM:S/BLIND CAMERA , AEM:ACTIVE ENG MOUNT , AS:ACTIVE SUS , ASCD:Auto Speed Controlo Device , CGC:CHG COMM , TETC:TK_ECU_TYPE_CLUCH , DC:DISTANCE CONTROL , MA:MOTOR ASSIST , IVMS:Integrated Voice-Messaging System , TQC:TORQ CONT , AP:ACCELE PEDAL , CON:CONVERTIBLE ROOF

Vehicle	Vehicle Type	Release Date	Eng	AT	ABS	BCM	IPC	ABG	ICC	HVAC	ITM	EPS	IPDM	APM	HLL	E-4WD	I-KEY	DIU	ASD	PSB	ADP	4WD	4WAS /RAS /HICAS	SONAR	LDW	NATS	SE	AIRL	RCM	SCM	AS	MA	IVMS	TCS	AP	ABD	CON	E-SUS	LAS	Break Cont	AUTO SLID	CANGATEWA	POPUP HOO	TOTAL ILLU	OCCUPANT	MULTI DISP	SVT
INFINITI M37/ M56/ M30d	Y51	2010 2011	SCD	SCD	SCD	SCD	CD	SCD	SCD	SCD	SCD		SCD	SCD	SCD					SCD	SCD	SCD	SCD	CD											SCD		SCD	SCD		SCD		SCD					
INFINITI EX25/ EX35	J50	2009 2011	SCD	SCD	SCD	SCD	SCD	SCD	SCD		SCD		SCD		SCD					SCD	SCD	SCD		CD	SCD										SCD					SCD							
INFINITI EX35	J50	2007 2008 2009 2010 2011	SCD	SCD	SCD	SCD	SCD	SCD	SCD		SCD		SCD		SCD					SCD	SCD	SCD		CD	SCD				SD						SCD					SCD							
INFINITI FX35/ FX45	S50	2003 2004 2005 2006 2007 2008	SCD	SCD	SCD	SCD	CD	SC	SCD	SCD	SCD	SCD	SCD	SCD	SCD	SCD	SCD	CD	SCD	SCD	SCD	SCD	SCD	CD	SCD	SC	CD	CD	SD	SD	SCD	CD	SCD	SCD						SCD							
INFINITI FX35/ FX50	S51	2008 2009 2010 2011	SCD	SCD	SCD	SCD	SCD	SCD	SCD		SCD		SCD	SCD	SCD					SCD	SCD	SCD	SCD	CD	SCD				SD						SCD			SCD		SCD		SCD					
INFINITI G20	P11	1999 2000 2001 2002	SCD	SCD	SCD	SCD	CD	SC	SCD	SCD	SCD	SCD	SCD	SCD	SCD	SCD	SCD	CD	SCD	SCD	SCD	SCD	SCD	CD	SCD	SC	CD	CD	SD	SD	SCD	CD	SCD	SCD						SCD							
INFINITI G25/G 37 Sedan	V36	2009 2010 2011	SCD	SCD	SCD	SCD	SCD	SCD	SCD		SCD		SCD		SCD					SCD	SCD	SCD	SCD	CD													SCD			SCD							
INFINITI G35 Coupe	CV35	2003 2004 2005 2006 2007	SCD	SCD	SCD	SCD	CD	SC	SCD	SCD	SCD	SCD	SCD	SCD	SCD	SCD	SCD	CD	SCD	SCD	SCD	SCD	SCD	CD	SCD	SC	CD	CD	SD	SD	SCD	CD	SCD	SCD						SCD							

INFINITI V10.11 Diagnostics List(Note:For reference only)

ILLUSTRATION: **S**:Sys. Info. **C**:DTC--Read code & Clear code **D**:Data Stream **T**:Action Test **F**:Special Functions(F1、F2、F3……)
F1:Function test(*) F2:Work Support(*) F3:Freeze Frame(*) F4:IDLE AIR VOL LEARN(*) F5:Calib Data (*) F6:Can Diag(*) F7:Can Diag Support Mntr (*) F8:DTC&SRT CONFIRMATION

HLL:HEAD LAMP LEVELIZER , LDW:LANE CAMERA , AFS:ADAPTIVE LIGHT , NATS:NATS IMMU , SE:SMART ENTRANCE , AIRL:AIR LEVELIZER , RCM:REARVIEW CAMERA , SCM:S/BLIND CAMERA , AEM:ACTIVE ENG MOUNT , AS:ACTIVE SUS , ASCD:Auto Speed Controlo Device , CGC:CHG COMM , TETC:TK_ECU_TYPE_CLUCH , DC:DISTANCE CONTROL , MA:MOTOR ASSIST , IVMS:Integrated Voice-Messaging System , TQC:TORQ CONT , AP:ACCELE PEDAL , CON:CONVERTIBLE ROOF

Vehicle	Vehicle Type	Release Date	Eng	AT	ABS	BCM	IPC	ABG	ICC	HVAC	ITM	EPS	IPDM	APM	HLL	E-4WD	I-KEY	DIU	ASD	PSB	ADP	4WD	4WAS /RAS /HICAS	SONAR	LDW	NATS	SE	AIRL	RCM	SCM	AS	MA	IVMS	TCS	AP	ABD	CON	E-SUS	LAS	Break Cont	AUTO SLID	CAN GAT EWA	POP UP HOO	TOTAL ILLU	OCC UPANT	MULTI DISP	SVT
INFINITI G35 Sedan	V36	2006 2007 2008	SCD		SCD	SCD	SCD	SCD	SCD		SCD		SCD		SCD					SCD	SCD	SCD	SCD	CD					SD											SCD							
INFINITI G35 Sedan	V35	2003 2004 2005 2006	SCD	SCD	SCD	SCD	CD	SC	SCD	SCD	SCD	SCD	SCD	SCD	SCD	SCD	SCD	CD	SCD	SCD	SCD	SCD	SCD	CD	SCD	SC	CD	CD	SD	SD	SCD	CD	SCD	SCD						SCD							
INFINITI G37 Convertible	HV36	2009 2010 2011	SCD	SCD	SCD	SCD	SCD	SCD	SCD		SCD		SCD		SCD					SCD	SCD	SCD	SCD	CD													SCD			SCD							
INFINITI G37 Coupe	CV36	2007 2008 2009 2010 2011	SCD	SCD	SCD	SCD	SCD	SCD	SCD		SCD		SCD		SCD					SCD	SCD	SCD	SCD	CD																SCD							
INFINITI G37 Sedan	V36	2008 2009 2010	SCD	SCD	SCD	SCD	SCD	SCD	SCD		SCD		SCD		SCD					SCD	SCD	SCD	SCD	CD													SCD			SCD							
INFINITI I30	CA32	1996 1997 1998 1999 2000 2001	SCD	SCD	SCD	SCD	CD	SC	SCD	SCD	SCD	SCD	SCD	SCD	SCD	SCD	SCD	CD	SCD	SCD	SCD	SCD	SCD	CD	SCD	SC	CD	CD	SD	SD	SCD	CD	SCD	SCD						SCD							
INFINITI I35	CA33	2002 2003 2004	SCD	SCD	SCD	SCD	CD	SC	SCD	SCD	SCD	SCD	SCD	SCD	SCD	SCD	SCD	CD	SCD	SCD	SCD	SCD	SCD	CD	SCD	SC	CD	CD	SD	SD	SCD	CD	SCD	SCD						SCD							
INFINITI M35/M45	Y50	2005 2006 2007 2008 2009 2010	SCD	SCD	SCD	SCD	CD	SC	SCD		SCD		SCD	SCD			SCD			SCD	SCD	SCD	SCD	CD	SCD				SD											SCD							
INFINITI M37/M56	Y51	2010 2011	SCD	SCD	SCD	SCD	CD	SCD	SCD	SCD	SCD		SCD	SCD	SCD					SCD	SCD	SCD	SCD	CD											SCD		SCD	SCD		SCD		SCD					

INFINITI V10.11 Diagnostics List(Note:For reference only)

ILLUSTRATION: **S**:Sys. Info. **C**:DTC--Read code & Clear code **D**:Data Stream **T**:Action Test **F**:Special Functions(F1、F2、F3……)
F1:Function test(*) F2:Work Support(*) F3:Freeze Frame(*) F4:IDLE AIR VOL LEARN(*) F5:Calib Data (*) F6:Can Diag(*) F7:Can Diag Support Mntr (*) F8:DTC&SRT CONFIRMATION

HLL:HEAD LAMP LEVELIZER , LDW:LANE CAMERA , AFS:ADAPTIVE LIGHT , NATS:NATS IMMU , SE:SMART ENTRANCE , AIRL:AIR LEVELIZER , RCM:REARVIEW CAMERA , SCM:S/BLIND CAMERA , AEM:ACTIVE ENG MOUNT , AS:ACTIVE SUS , ASCD:Auto Speed Controlo Device , CGC:CHG COMM , TETC:TK_ECU_TYPE_CLUCH , DC:DISTANCE CONTROL , MA:MOTOR ASSIST , IVMS:Integrated Voice-Messaging System , TQC:TORQ CONT , AP:ACCELE PEDAL , CON:CONVERTIBLE ROOF

Vehicle	Vehicle Type	Release Date	Eng	AT	ABS	BCM	IPC	ABG	ICC	HVAC	ITM	EPS	IPDM	APM	HLL	E-4WD	I-KEY	DIU	ASD	PSB	ADP	4WD	4WAS /RAS /HICAS	SONAR	LDW	NATS	SE	AIRL	RCM	SCM	AS	MA	IVMS	TCS	AP	ABD	CON	E-SUS	LAS	Break Cont	AUTO SLID	CANGAT EWA	POPUP HOO	TOTAL ILLU	OCCUPANT	MULTI DISP	SVT
INFINITI M45	Y34	2003 2004 2005	SCD	SCD	SCD	SCD	CD	SC	SCD	SCD	SCD	SCD	SCD	SCD	SCD	SCD	SCD	CD	SCD	SCD	SCD	SCD	SCD	CD	SCD	SC	CD	CD	SD	SD	SCD	CD	SCD	SCD						SCD							
INFINITI Q45	FY33	1995 1996 1997 1998 1999 2000 2001	SCD	SCD	SCD	SCD	CD	SC	SCD	SCD	SCD	SCD	SCD	SCD	SCD	SCD	SCD	CD	SCD	SCD	SCD	SCD	SCD	CD	SCD	SC	CD	CD	SD	SD	SCD	CD	SCD	SCD						SCD							
INFINITI Q45	F50	2001 2002 2003 2004 2005 2006*	SCD	SCD	SCD	SCD	CD	SC	SCD	SCD	SCD	SCD	SCD	SCD	SCD	SCD	SCD	CD	SCD	SCD	SCD	SCD	SCD	CD	SCD	SC	CD	CD	SD	SD	SCD	CD	SCD	SCD						SCD							
INFINITI QX4	JR50	1997 1998 1999 2000 2001 2002 2003	SCD	SCD	SCD	SCD	CD	SC	SCD	SCD	SCD	SCD	SCD	SCD	SCD	SCD	SCD	CD	SCD	SCD	SCD	SCD	SCD	CD	SCD	SC	CD	CD	SD	SD	SCD	CD	SCD	SCD						SCD							
INFINITI QX56	Z62	2010 2011	SCD	SCD	SCD	SCD	CD	SCD	SCD	SCD	SCD		SCD	SCD	SCD					SCD	SCD			CD					SD					SCD	SCD				SCD		SCD					
INFINITI QX56	JA60	2004 2005 2006 2007 2008 2009 2010	SCD	SCD	SCD	SCD	CD	SC	SCD	SCD	SCD	SCD	SCD	SCD	SCD	SCD	SCD	CD	SCD	SCD	SCD	SCD	SCD	CD	SCD	SC	CD	CD	SD	SD	SCD	CD	SCD	SCD						SCD							
INFINITI EX35/ EX30d	J50	2009 2010 2011	SCD	SCD	SCD	SCD	SCD	SCD	SCD		SCD		SCD		SCD					SCD	SCD	SCD		CD	SCD										SCD					SCD							
INFINITI EX37	J50	2008 2009	SCD	SCD	SCD	SCD	SCD	SC	SCD		SCD		SCD	SCD	SCD						SCD	SCD		CD					SD											SCD							

INFINITI V10.11 Diagnostics List(Note:For reference only)

ILLUSTRATION: **S**:Sys. Info. **C**:DTC--Read code & Clear code **D**:Data Stream **T**:Action Test **F**:Special Functions(F1、F2、F3……)
F1:Function test(*) F2:Work Support(*) F3:Freeze Frame(*) F4:IDLE AIR VOL LEARN(*) F5:Calib Data (*) F6:Can Diag(*) F7:Can Diag Support Mntr (*) F8:DTC&SRT CONFIRMATION

HLL:HEAD LAMP LEVELIZER , LDW:LANE CAMERA , AFS:ADAPTIVE LIGHT , NATS:NATS IMMU , SE:SMART ENTRANCE , AIRL:AIR LEVELIZER , RCM:REARVIEW CAMERA , SCM:S/BLIND CAMERA , AEM:ACTIVE ENG MOUNT , AS:ACTIVE SUS , ASCD:Auto Speed Controlo Device , CGC:CHG COMM , TETC:TK_ECU_TYPE_CLUCH , DC:DISTANCE CONTROL , MA:MOTOR ASSIST , IVMS:Integrated Voice-Messaging System , TQC:TORQ CONT , AP:ACCELE PEDAL , CON:CONVERTIBLE ROOF

Vehicle	Vehicle Type	Release Date	Eng	AT	ABS	BCM	IPC	ABG	ICC	HVAC	ITM	EPS	IPDM	APM	HLL	E-4WD	I-KEY	DIU	ASD	PSB	ADP	4WD	4WAS /RAS /HICAS	SONAR	LDW	NATS	SE	AIRL	RCM	SCM	AS	MA	IVMS	TCS	AP	ABD	CON	E-SUS	LAS	Break Cont	AUTO SLID	CANGAT EWA	POPUP HOO	TOTAL ILLU	OCCUPANT	MULTI DISP	SVT
INFINITI FX37/ FX50	S51	2008 2009	SCD	SCD	SCD	SCD	SCD	SC	SCD		SCD		SCD	SCD	SCD						SCD	SCD	SCD	CD														SCD		SCD							
INFINITI FX37/ FX50/ FX30d	S51	2009 2010	SCD	SCD	SCD	SCD	SCD	SCD	SCD		SCD		SCD	SCD	SCD					SCD	SCD	SCD	SCD	CD	SCD				SD									SCD		SCD		SCD					
INFINITI M37/ M56/ M30d	Y51	2010 2011	SCD	SCD	SCD	SCD	CD	SCD	SCD	SCD	SCD		SCD	SCD	SCD					SCD	SCD	SCD	SCD	CD											SCD		SCD	SCD		SCD		SCD					
INFINITI EX25/ EX35	J50	2009 2011	SCD	SCD	SCD	SCD	SCD	SCD	SCD		SCD		SCD		SCD					SCD	SCD	SCD		CD	SCD										SCD					SCD							
INFINITI M25/ M37	Y51	2010 2011	SCD	SCD	SCD	SCD	CD	SCD	SCD	SCD	SCD		SCD	SCD	SCD					SCD	SCD	SCD	SCD	CD											SCD		SCD	SCD		SCD		SCD					
INFINITI EX35(DOM)	J50	2009 2010	SCD	SCD	SCD	SCD	SCD	SCD	SCD		SCD		SCD		SCD					SCD	SCD	SCD		CD	SCD										SCD					SCD							
INFINITI EX35/ EX37	J50	2011	SCD	SCD	SCD	SCD	SCD	SCD	SCD		SCD		SCD		SCD					SCD	SCD	SCD		CD	SCD										SCD					SCD							