

Japanese Isuzu **V11.11** Diagnostics List (Note: For reference only)

Year	Vehicle	Module	System	Sub System	Functions						
					Sys. Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Functions	Others
2010	TF/UC Series	Engine	3.0L 4JJ1-TC (Delphi)		√	√	√	√			
			3.0L 4JJ1-TC (TransTron)		√	√	√	√			
2009	TF/UC Series	Engine	2.4L LG1 Euro 3		√	√	√	√			
			2.5L 4JK1-TC (Delphi)		√	√	√	√			
			2.5L 4JK1-TC (TransTron)		√	√	√	√			
			3.0L 4JJ1-TC (Delphi)		√	√	√	√			
			3.0L 4JJ1-TC (TransTron)		√	√	√	√			
			V6 Engine		√	√	√	√			
		Transmission	AW30-40LE		√	√	√	√			
			Automatic Transmission		√	√	√	√			
		Chassis	ABS		√	√	√	√			
		Body	Immobiliser (2.4L LG1 Euro3)		√	√	√	√			
			Immobiliser (Delphi)		√	√	√	√			
			Immobiliser (Transtron)		√	√	√	√			
			Immobiliser (V6 Engine)		√	√	√	√			
			Airbag		√	√	√	√			
Powertrain Interface Module			√	√	√	√					
		Engine	2.4L LG1 Euro 3		√	√	√	√			
			2.5L 4JK1-TC (Delphi)		√	√	√	√			
			2.5L 4JK1-TC (TransTron)		√	√	√	√			
			3.0L 4JJ1-TC (Delphi)		√	√	√	√			
			3.0L 4JJ1-TC (TransTron)		√	√	√	√			
			V6 Engine		√	√	√	√			
			2. XL L4 HV240			√	√	√			
			4JA1-TC Bosch			√	√	√			
			4JH1-TC Bosch			√	√	√			
			AT JR405E			√	√	√			
			AW30-40LE			√	√	√			

Japanese Isuzu **V11.11** Diagnostics List (Note: For reference only)

Year	Vehicle	Module	System	Sub System	Functions						
					Sys. Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Functions	Others
	TF/UC Series	Transmission	AW30-40LE		√	√	√	√			
			Automatic Transmission		√	√	√	√			
		Chassis	ABS		√	√	√	√			
			ABS 8			√	√	√			
			ABS (VPW)			√	√	√			
		Body	Immobiliser (2.4L LG1 Euro3)		√	√	√	√			
			Immobiliser (Delphi)		√	√	√	√			
			Immobiliser (Transtron)		√	√	√	√			
			Immobiliser (V6 Engine)		√	√	√	√			
			Airbag		√	√	√	√			
	Powertrain Interface Module			√	√	√	√				
		Airbag (VPW)			√	√	√				
	N Series Truck	Engine	4HK1-TC (C/Rail)		√	√	√	√			
			4JJ1-TC (C/Rail)		√	√	√	√			
			4HV1<CNG>			√	√	√			
			4HK1/4JJ1 <C/Rail_Euro2>			√	√	√			
			4HK1/6HK1 <C/Rail_Euro3>			√	√	√			
			4HK1-TC <C/Rail_NLT>			√	√	√			
4JH1-TC Bosch					√	√	√				
4JJ1-TC <C/Rail_NLT>					√	√	√				
Idle stop <BCM>					√	√	√				
Hybrid System					√	√	√				
Body		Immobiliser		√	√	√	√				
		Airbag			√	√	√				
		Vehicle Body Control Module			√	√	√				
Chassis		ABS/ASR			√	√	√				
Transmission		AT A460			√	√	√				

Japanese Isuzu V11.11Diagnostics List(Note:For reference only)

Year	Vehicle	Module	System	Sub System	Functions						
					Sys. Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Functions	Others
2008		Transmission	Smoother / Smoother-Ex			√	√	√			
		Information System	MIMAMORI			√	√	√			
	F&G Series Truck	Engine	4HK1-TC (C/Rail)		√	√	√	√			
			6HK1-TC (C/Rail)		√	√	√	√			
			4HK1/6HK1 <C/Rail_Euro2>			√	√	√			
			4HK1/6HK1 <C/Rail_Euro3>			√	√	√			
			4HK1-TC <C/Rail_NLT>			√	√	√			
			6HK1-TC <C/Rail_NLT>			√	√	√			
			Idle stop <BCM>			√	√	√			
			6UZ1-TC <C/Rail_Euro3>			√	√	√			
		Body	Immobiliser		√	√	√	√			
			Airbag			√	√	√			
			Vehicle Body Control Module			√	√	√			
		Information System	MIMAMORI			√	√	√			
			Speedometer Control Equipment					√			
		Transmission									
	Smoother / Smoother-Fx					√	√	√			
			Automatic Transmission		√	√	√	√			

Japanese Isuzu **V11.11** Diagnostics List (Note: For reference only)

Year	Vehicle	Module	System	Sub System	Functions						
					Sys. Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Functions	Others
C&E Series Truck	Engine	6WG1-TC (C/Rail)		√	√	√	√				
		6WG1-TC (C/Rail_NLT)		√	√	√	√				
		6UZ1-TC <C/Rail_NLT>		√	√	√	√				
	Body	Drive security reference		√	√	√	√				
	Chassis	Air Suspension		√	√	√	√				
		Millimeter wave radar cruise		√	√	√	√				
	Information System	MIMAMORI			√	√	√				
	LT/LV Series Bus	Engine	6HK1-TC (C/Rail)		√	√	√	√			
			6HK1-TC <C/Rail_NLT>			√	√	√			
			6UZ1-TC <C/Rail_Euro3>			√	√	√			
Transmission		Automatic Transmission		√	√	√	√				
Off-Road Serial Industrial Engine	Engine	4JJ1-TC <C/Rail_Tier3>		√	√	√	√				
		4HK1-TC <C/Rail_Tier3>		√	√	√	√				
		6HK1-TC <C/Rail_Tier3>		√	√	√	√				
		6UZ1-TC <C/Rail_Tier3>		√	√	√	√				
		6WG1-TC <C/Rail_Tier3>		√	√	√	√				
		2.4L LG1 Euro 3		√	√	√	√				

Japanese Isuzu **V11.11** Diagnostics List (Note: For reference only)

Year	Vehicle	Module	System	Sub System	Functions							
					Sys. Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Functions	Others	
	TF/UC Series	Engine	2.5L 4JK1-TC (Delphi)		√	√	√	√				
			3.0L 4JJ1-TC (Delphi)		√	√	√	√				
			V6 Engine		√	√	√	√				
			2. XL L4 HV240			√	√	√				
			4JA1-TC Bosch			√	√	√				
			4JH1-TC Bosch			√	√	√				
			AT JR405E			√	√	√				
			AW30-40LE			√	√	√				
		Transmission	AW30-40LE		√	√	√	√				
			Automatic Transmission		√	√	√	√				
		Chassis	ABS		√	√	√	√				
			ABS 8			√	√	√				
			ABS (VPW)			√	√	√				
		Body	Immobiliser (2.4L LG1 Euro3)		√	√	√	√				
			Immobiliser (Delphi)		√	√	√	√				
			Immobiliser (V6 Engine)		√	√	√	√				
			Airbag		√	√	√	√				
			Powertrain Interface Module		√	√	√	√				
			Anti Theft Warning		√	√	√	√				
			Airbag (VPW)			√	√	√				
			Airbag SIEMENS			√	√	√				
		N Series Truck	Engine	4HK1-TC (C/Rail)		√	√	√	√			
				4JJ1-TC (C/Rail)		√	√	√	√			
				4HV1<CNG>			√	√	√			
				4HK1-TC <C/Rail_NLT>			√	√	√			
				4JH1-TC Bosch			√	√	√			
				4JJ1-TC <C/Rail_NLT>			√	√	√			
				Idle stop <BCM>			√	√	√			
Hybrid System					√	√	√					

Japanese Isuzu V11.11Diagnostics List(Note:For reference only)

Year	Vehicle	Module	System	Sub System	Functions						
					Sys. Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Functions	Others
2007		Body	Airbag			√	√	√			
			Vehicle Body Control Module			√	√	√			
		Chassis	ABS/ASR			√	√	√			
		Transmission	AT A460			√	√	√			
		Information System	MIMAMORI			√	√	√			
	F&G Series Truck	Engine	6HK1-TC (C/Rail)		√	√	√	√			
			Idle stop <BCM>			√	√	√			
			4HK1-TC <C/Rail_NLT>			√	√	√			
			6HK1-TC <C/Rail_NLT>			√	√	√			
		Body	Airbag			√	√	√			
			Vehicle Body Control Module			√	√	√			
		Transmission	Automatic Transmission		√	√	√	√			
			Smoother / Smoother-Fx			√	√	√			
	Information System	MIMAMORI			√	√	√				
		Speedometer Control Equipment					√				
C&E Series Truck	Engine	6WG1-TC (C/Rail)		√	√	√	√				
		6WG1-TC (C/Rail_NLT)		√	√	√	√				
		6UZ1-TC <C/Rail_NLT>		√	√	√	√				
	Body	Drive security reference		√	√	√	√				
	Chassis	Air Suspension		√	√	√	√				
		Millimeter wave radar cruise		√	√	√	√				
Information System	MIMAMORI			√	√	√					
LT/LV Series Bus	Engine	6HK1-TC (C/Rail)		√	√	√	√				
		6UZ1-TC <C/Rail Euro3>			√	√	√				
	Transmission:	Automatic Transmission		√	√	√	√				
Off-Road		4JJ1-TC <C/Rail_Tier3>		√	√	√	√				
		4HK1-TC <C/Rail_Tier3>		√	√	√	√				

Japanese Isuzu **V11.11** Diagnostics List (Note: For reference only)

Year	Vehicle	Module	System	Sub System	Functions						
					Sys. Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Functions	Others
2006	Serial Industrial Engine	Engine	6HK1-TC <C/Rail_Tier3>		√	√	√	√			
			6UZ1-TC <C/Rail_Tier3>		√	√	√	√			
			6WG1-TC <C/Rail_Tier3>		√	√	√	√			
	TF/UC Series	Engine	2.4L LG1 Euro 3		√	√	√	√			
			V6 Engine		√	√	√	√			
			2. XL L4 HV240			√	√	√			
			4JA1-TC Bosch			√	√	√			
			4JH1-TC Bosch			√	√	√			
			AT JR405E			√	√	√			
			AW30-40LE			√	√	√			
		Transmission	Automatic Transmission		√	√	√	√			
		Chassis	ABS		√	√	√	√			
			ABS (VPW)			√	√	√			
		Body	Immobiliser		√	√	√	√			
			Airbag		√	√	√	√			
			Powertrain Interface Module		√	√	√	√			
			Airbag (VPW)			√	√	√			
		N Series Truck	Engine	4HV1<CNG>			√	√	√		
	4HG1<LPG>					√	√	√			
	4JG2<LPG>					√	√	√			
	4JG2					√	√	√			
4JH1-TC Bosch					√	√	√				
Hybrid System					√	√	√				
Chassis	ABS/ASR				√	√	√				
Transmission	Smoother/Smoother-E Auto Shift				√	√	√				
	Smoother-E			√	√	√					

Japanese Isuzu **V11.11** Diagnostics List (Note: For reference only)

Year	Vehicle	Module	System	Sub System	Functions								
					Sys. Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Functions	Others		
	<C*,E*,L*,F*> Heavy, Medium Duty	Chassis	ABS ASR ADVICS			√	√	√					
	Off-Road Serial Industrial Engine	Engine	4JJ1-TC <C/Rail_Tier3>		√	√	√	√					
			4HK1-TC <C/Rail_Tier3>		√	√	√	√					
			6HK1-TC <C/Rail_Tier3>		√	√	√	√					
			6UZ1-TC <C/Rail_Tier3>		√	√	√	√					
6WG1-TC <C/Rail_Tier3>				√	√	√	√						
2005	(TF/UC)LUV, Rodeo/Frontier , LAO-Rodeo	Powertrain	2.5L 4JK1-TC			√	√	√					
			3.0L 4JJ1-TC			√	√	√					
			4JH1-T Denso			√	√	√					
			2. XL L4 HV240			√	√	√					
			4JA1-TC Bosch			√	√	√					
			4JH1-TC Bosch			√	√	√					
			AT JR405E			√	√	√					
		Chassis	AW30-40LE			√	√	√					
			ABS			√	√	√					
		Body	ABS (VPW)			√	√	√					
			Immobiliser (kwp D_MAX_IMMO)		√	√	√	√					
			Airbag			√	√	√					
		N Series Truck	Engine	Airbag (VPW)			√	√	√				
				4HV1<CNG>			√	√	√				
				4HG1<LPG>			√	√	√				
4JG2<LPG>					√	√	√						
4JG2					√	√	√						
4JH1-TC Bosch					√	√	√						
MIMAMORI					√	√	√						
Hybrid System			√	√	√								

Japanese Isuzu **V11.11** Diagnostics List (Note: For reference only)

Year	Vehicle	Module	System	Sub System	Functions							
					Sys. Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Functions	Others	
2004		Chassis	ABS/ASR			√	√	√				
		Transmission	Smoother/Smoother-E Auto Shift			√	√	√				
	<C*,E*,L*,F*>	Transmission	AT Allison LCT			√	√	√				
	Heavy, Medium Duty	Chassis	ABS ASR ADVICS			√	√	√				
	Off-Road Serial Industrial Engine	Engine	4JJ1-TC <C/Rail_Tier3>		√	√	√	√				
			4HK1-TC <C/Rail_Tier3>		√	√	√	√				
			6HK1-TC <C/Rail_Tier3>		√	√	√	√				
			6UZ1-TC <C/Rail_Tier3>		√	√	√	√				
			6WG1-TC <C/Rail_Tier3>		√	√	√	√				
	(UE) Rodeo/Amigo, Wizard/MU	Powertrain	3.2L V6 6VD1			√	√	√				
			3.2L V6 6VD1 Hitachi			√	√	√				
			4JG2			√	√	√				
		Chassis	ABS			√	√	√				
			Body	Immobiliser		√	√	√	√			
				AirBag			√	√	√			
Airbag (VPW)					√	√	√					
(TF/UC)LUV, Rodeo/Frontier, LAO-Rodeo		Powertrain	2.5L 4JK1-TC			√	√	√				
			3.0L 4JJ1-TC			√	√	√				
			4JH1-T Denso			√	√	√				
	4JG2				√	√	√					
	2. XL L4 HV240				√	√	√					
	4JA1-TC Bosch				√	√	√					
	4JH1-TC Bosch				√	√	√					
	AT JR405E				√	√	√					
	AW30-40LE			√	√	√						
	Chassis	ABS			√	√	√					
		ABS (VPW)			√	√	√					
			Immobiliser		√	√	√	√				

Japanese Isuzu **V11.11** Diagnostics List (Note: For reference only)

Year	Vehicle	Module	System	Sub System	Functions							
					Sys. Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Functions	Others	
<N*> ELF, NPR, NOR, VFR	Body	Airbag			√	√	√					
		Airbag (VPW)			√	√	√					
	Engine	4HF1<CNG>				√	√	√				
		4HG1<LPG>				√	√	√				
		4JG2<LPG>				√	√	√				
		4JG2				√	√	√				
		4JH1-TC Bosch				√	√	√				
		MIMAMORI				√	√	√				
		Hybrid System				√	√	√				
	Chassis	ABS/ASR				√	√	√				
	Transmission	Smoother/Smoother-E Auto Shift				√	√	√				
		AT Allison LCT				√	√	√				
	<C*,E*,L*,F*> Heavy, Medium Duty	Transmission	AT Allison LCT			√	√	√				
	Chassis	ABS ASR ADVICS			√	√	√					
(UB) Trooper, Bighorn	Powertrain	3.0L L4 4JX1			√	√	√					
		3.2L V6 6VD1			√	√	√					
		3.5L V6 6VE1			√	√	√					
	Body											
(UE) Rodeo/Amigo, Wizard/MU	Powertrain	3.0L L4 4JX1			√	√	√					
		3.2L V6 6VD1			√	√	√					
	Chassis	ABS			√	√	√					
	Body	Immobiliser			√	√	√					
(UP) Axiom	Powertrain	3.5L V6 6VE1			√	√	√					
	Chassis	ABS			√	√	√					

Japanese Isuzu V11.11Diagnostics List (Note:For reference only)

Year	Vehicle	Module	System	Sub System	Functions						
					Sys. Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Functions	Others
2002	(UP) Axiom	Powertrain	3.5L V6 6VE1			√	√	√			
		Chassis	ABS			√	√	√			
		Body									
	TF/UC Thailand	Powertrain	4JH1-T Denso			√	√	√			
	(TF/UC) LUV,Frontier, LAO-Rodeo	Powertrain	D-MAX(4JH1-T Denso)			√	√	√			
			3.2L V6 6VD1 Hitachi			√	√	√			
		4JA1-TC Bosch			√	√	√				
		4JH1-TC Bosch			√	√	√				
		AT JR405E			√	√	√				
	Body	AirBag			√	√	√				
	<N*> ELF,NPR,NOR, VFR	Engine	4JH1-TC Bosch			√	√	√			
Chassis		ABS/ASR			√	√	√				
<C*,E*,L*,F*> Heavy, Medium Duty	Transmission	AT Allison LCT			√	√	√				
(UB) Trooper, Bighorn	Powertrain	3.0L L4 4JX1			√	√	√				
		3.2L V6 6VD1			√	√	√				
		3.5L V6 6VE1			√	√	√				
	Body										
(UE) Rodeo/Amigo, Wizard/MU	Powertrain	2.2L L4 X22SE			√	√	√				
		3.0L L4 4JX1			√	√	√				
		3.2L V6 6VD1			√	√	√				
	Chassis	ABS			√	√	√				

Japanese Isuzu **V11.11** Diagnostics List (Note: For reference only)

Year	Vehicle	Module	System	Sub System	Functions							
					Sys. Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Functions	Others	
2001		Body										
	(UC) Frontier ,LAO-Rodeo	Powertrain	4ZE1			√	√	√				
			3.2L V6 6VD1 Hitachi			√	√	√				
		Body				√	√	√				
	(TF) LUV	Powertrain										
			3.2L V6 6VD1 Hitachi			√	√	√				
			4JA1-TC Bosch			√	√	√				
		4JH1-TC Bosch			√	√	√					
		Body				√	√	√				
	TF/UC Thailand	Powertrain	D-MAX	4JH1-T Denso			√	√	√			
	(TBR)	Powertrain	2.0L L4 SOHC				√	√	√			
			2.2L L4 SOHC				√	√	√			
	<N*> ELF,NPR,NOR,	Engine	4JH1-TC Bosch				√	√	√			
		Chassis	ABS/ASR				√	√	√			
	<TF/UC> LUV, Rodeo/Frontier , LAO-Rodeo	Powertrain	3.2L V6 6VD1 Hitachi				√	√	√			
4JA1-TC Bosch						√	√	√				
4JH1-TC Bosch						√	√	√				
<UG> V-Cross	Powertrain	3.2L V6 6VD1					√	√				
		3.5L V6 6VE1					√	√				
(UB) Trooper, Bighorn	Powertrain	3.0L L4 4JX1				√	√	√				
		3.2L V6 6VD1				√	√	√				
		3.5L V6 6VE1				√	√	√				
	Body											
(UE)	Powertrain	2.2L L4 X22SE				√	√	√				
		3.0L L4 4JX1				√	√	√				

Japanese Isuzu **V11.11** Diagnostics List (Note: For reference only)

Year	Vehicle	Module	System	Sub System	Functions						
					Sys. Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Functions	Others
2000	Rodeo/Amigo, Wizard/MU		3.2L V6 6VD1			√	√	√			
		Chassis	ABS			√	√	√			
		Body									
	(UG) V-Cross	Powertrain	3.2L V6 6VD1			√	√	√			
			3.5L V6 6VE1			√	√	√			
		Body									
		(UC) Frontier, LAO-Rodeo	Powertrain	4ZE1			√	√	√		
			3.2L V6 6VD1 Hitachi			√	√	√			
		Body									
		(TF) LUV	Powertrain								
			3.2L V6 6VD1 Hitachi			√	√	√			
		Body									
		(TBR)	Powertrain								
	<N*>ELF,NPR, NOR,VFR	Chassis	ABS/ASR				√	√	√		
<TF/UC> LUV, Rodeo/Frontier, LAO-Rodeo	Powertrain	3.2L V6 6VD1 Hitachi			√	√	√				
		4JA1-TC Bosch			√	√	√				
		4JH1-TC Bosch			√	√	√				
(UB) Trooper, Bighorn	Powertrain	3.0L L4 4JX1			√	√	√				
		3.2L V6 6VD1			√	√	√				
		3.5L V6 6VE1			√	√	√				
	Body										
(UE)	Powertrain	2.2L L4 X22SE			√	√	√				
		3.0L L4 4JX1			√	√	√				

Japanese Isuzu **V11.11** Diagnostics List (Note: For reference only)

Year	Vehicle	Module	System	Sub System	Functions						
					Sys. Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Functions	Others
1999	Rodeo/Amigo, Wizard/MU		3.2L V6 6VD1			√	√	√			
		Chassis	ABS			√	√	√			
		Body									
	(UG) V-Cross	Powertrain	3.2L V6 6VD1			√	√	√			
			3.5L V6 6VE1			√	√	√			
		Body									
	(UC) Frontier, LAO-Rodeo	Powertrain	3.2L V6 6VD1 Hitachi			√	√	√			
	(TF) LUV	Powertrain									
			3.2L V6 6VD1 Hitachi			√	√	√			
	(TBR)	Powertrain	2.2L L4 SOHC			√	√	√			
<N*>ELF,NPR, NOR,VFR	Chassis	ABS/ASR			√	√	√				
<TF/UC> LUV, Rodeo/Frontier, LAO-Rodeo	Powertrain	3.2L V6 6VD1 Hitachi			√	√	√				
	(UB) Trooper, Bighorn	Powertrain	3.0L L4 4JX1			√	√	√			
			3.2L V6 6VD1			√	√	√			
			3.5L V6 6VE1			√	√	√			
		Body									
	(UE) Rodeo/Amigo, Wizard/MU	Powertrain	2.2L L4 X22SE			√	√	√			
			3.0L L4 4JX1			√	√	√			
3.2L V6 6VD1					√	√	√				

Japanese Isuzu V11.11Diagnostics List(Note:For reference only)

Year	Vehicle	Module	System	Sub System	Functions						
					Sys. Info.	Read DTC	Clear DTC	Data Stream	Actuation	Special Functions	Others
1998		Chassis	ABS			√	√	√			
		Body									
	(TF) LUV	Powertrain									
			3.2L V6 6VD1 Hitachi			√	√	√			
	(TBR)	Powertrain	2.2L L4 SOHC			√	√	√			
<TF/UC> LUV, Rodeo/Frontier , LAO-Rodeo	Powertrain	3.2L V6 6VD1 Hitachi				√	√	√			