

Nissan V10.20 Diagnostics List (Note:For reference only)

ILLUSTRATION: S:Sys. Info. C:DTC--Read code & Clear code D:Data Stream

HLL:HEAD LAMP LEVELIZER, LDW:LANE CAMERA, AFS:ADAPTIVE LIGHT, NATS:NATS IMMU, SE:SMART ENTRANCE, AIRL:AIR LEVELIZER, RCM:REARVIEW CAMERA, SCM:S/BLIND CAMERA, AEM:ACTIVE ENG MOUNT, AS:ACTIVE SUS, ASCD:Auto Speed Control Device, CGC:CHG COMM, TETC:TK_ECU_TYPE_CLUCH, DC:DISTANCE CONTROL, MA:MOTOR ASSIST, IVMS:Integrated Voice-Messaging System, TQC:TORQ CONT, AP:ACCELE PEDAL, CON:CONVERTIBLE ROOF

Vehicle	Vehicle Type	Release Date	Eng	AT	ABS	BCM	IPC	ABG	ICC	HVAC	ITM	EPS	IPDM	APM	HLL	E-4WD	I-KEY	DIU	ASD	PSB	ADP	4WD	4WAS/RAS/HICAS	SONAR	LDW	NATS	SE	AIRL	RCM	SCM	AS	MA	IVMS	TCS	AP	ABD	CON	E-SUS	LAS	Break Cont	AUTO SLID	CAN GAT EWA	POP UP HOO	TOTAL ILLU	OCC UPNT	MULTI DISP	SVT				
350Z	Z33	2002																																																	
		2003																																																	
		2004																																																	
		2005																																																	
		2006																																																	
		2007																																																	
		2008-2009	SCD	SCD	SCD	SCD	CD	SCD	SCD	SCD	SCD	SCD	SCD	SCD	SCD	SCD	SCD	SCD	CD	SCD	SCD	SCD	SCD	SCD	CD	SCD	SCD	CD	SD	SD	SCD	CD	SCD	SCD									SCD								
370Z	Z34	2008																																																	
		2009																																																	
		2010	SCD	SCD	SCD	SCD	CD	SCD	SCD	SCD	SCD	SCD	SCD	SCD	SCD	SCD		SCD																																	
		2011	SCD	SCD	SCD	SCD	CD	SCD	SCD	SCD	SCD	SCD	SCD	SCD	SCD	SCD		SCD						SCD																											
370Z Convertible	HZ34	2009-2011	SCD	SCD	SCD	SCD	CD	SCD	SCD	SCD	SCD	SCD	SCD	SCD	SCD																																				
ALTIM A	L32	2006																																																	
		2007																																																	
		2008																																																	
		2009																																																	
		2010-2011	SCD	SCD	SCD	SCD	CD	SCD	SCD	SCD	SCD	SCD	SCD	SCD	SCD	SCD	SCD																																		
ALTIM A	L31	2001																																																	
		2002																																																	
		2003																																																	
		2004																																																	
		2005	SCD	SCD	SCD	SCD	CD	SCD	SCD	SCD	SCD	SCD	SCD	SCD	SCD	SCD	SCD	SCD	CD	SCD	SCD	SCD	SCD	SCD	CD	SCD	SCD	CD	SD	SD	SCD	CD	SCD	SCD	SCD																
		2006*	SCD	SCD	SCD	SCD	CD	SCD	SCD	SCD	SCD	SCD	SCD	SCD	SCD	SCD	SCD	SCD	CD	SCD	SCD	SCD	SCD	SCD	CD	SCD	SCD	CD	SD	SD	SCD	CD	SCD	SCD	SCD																
ALTIM A	L30	1997																																																	
		1998																																																	
		1999	SCD	SCD	SCD	SCD	CD	SCD	SCD	SCD	SCD	SCD	SCD	SCD	SCD	SCD	SCD	SCD	CD	SCD	SCD	SCD	SCD	SCD	CD	SCD	SCD	CD	SD	SD	SCD	CD	SCD	SCD	SCD																
		2000*	SCD	SCD	SCD	SCD	CD	SCD	SCD	SCD	SCD	SCD	SCD	SCD	SCD	SCD	SCD	SCD	CD	SCD	SCD	SCD	SCD	SCD	CD	SCD	SCD	CD	SD	SD	SCD	CD	SCD	SCD	SCD																
		2007-2011	SCD	SCD	SCD	SCD	CD	SCD	SCD	SCD	SCD	SCD	SCD	SCD	SCD	SCD	SCD																																		

Nissan V10.20 Diagnostics List (Note:For reference only)

ILLUSTRATION: **S:**Sys. Info **C:**DTC--Read code & Clear code **D:**Data Stream

HLL:HEAD LAMP LEVELIZER , LDW:LANE CAMERA , AFS:ADAPTIVE LIGHT , NATS:NATS IMMUI , SE:SMART ENTRANCE , AIRL:AIR LEVELIZER , RCM:REARVIEW CAMERA , SCM:S/BLIND CAMERA , AEM:ACTIVE ENG MOUNT , AS:ACTIVE SUS , ASCD:Auto Speed Control Device , CGC:CHG COMM , TETC:TK_ECU_TYPE_CLUCH , DC:DISTANCE CONTROL , MA:MOTOR ASSIST , IVMS:Integrated Voice-Messaging System , TQC:TORQ CONT , AP:ACCELE PEDAL , CON:CONVERTIBLE ROOF

Vehicle	Vehicle Type	Release Date	Eng	AT	ABS	BCM	IPC	ABG	ICC	HVAC	ITM	EPS	IPDM	APM	HLL	E-4WD	I-KEY	DIU	ASD	PSB	ADP	4WD	4WAS/RAS/HICAS	SONAR	LDW	NATS	SE	AIRL	RCM	SCM	AS	MA	IVMS	TCS	AP	ABD	CON	E-SUS	LAS	Break Cont	AUTO SLID	CAN GAT EWA	POP UP HOO	TOTAL ILLU	OCC UPANT	MULTI DISP	SVT								
INFINITI FX35/FX50	S51	2008 2009 2010 2011	SCD	SCD	SCD	SCD	SCD	SCD	SCD	SCD	SCD	SCD	SCD	SCD	SCD					SCD	SCD	SCD	SCD		SCD										SCD			SCD																	
INFINITI G20	P11	1999 2000 2001 2002	SCD	SCD	SCD	SCD	CD	SC	SCD	SCD	SCD	SCD	SCD	SCD	SCD	SCD	SCD	CD	SCD	SCD	SCD	SCD	SCD		SCD		C	CD	SD	SD												SCD													
INFINITI G25/G37 Sedan	V36	2009 2010 2011	SCD	SCD	SCD	SCD	SCD	SCD	SCD		SCD	SCD			SCD					SCD	SCD	SCD	SCD																				SCD												
INFINITI G35 Coupe	CV35	2003 2004 2005 2006 2007	SCD	SCD	SCD	SCD	CD	SC	SCD	SCD	SCD	SCD	SCD	SCD	SCD	SCD	SCD	CD	SCD	SCD	SCD	SCD	SCD		SCD		C	CD	SD	SD																SCD									
INFINITI G35 Sedan	V36	2006 2007 2008	SCD		SCD	SCD	SCD	SCD	SCD		SCD	SCD			SCD					SCD	SCD	SCD	SCD																								SCD								
INFINITI G35 Sedan	V35	2003 2004 2005 2006	SCD	SCD	SCD	SCD	CD	SC	SCD	SCD	SCD	SCD	SCD	SCD	SCD	SCD	SCD	CD	SCD	SCD	SCD	SCD	SCD		SCD		C	CD	SD	SD																		SCD							
INFINITI G37 Convertible	HV36	2009 2010 2011	SCD	SCD	SCD	SCD	SCD	SCD	SCD		SCD	SCD			SCD					SCD	SCD	SCD	SCD																								SCD								
INFINITI G37 Coupe	CV36	2007 2008 2009 2010 2011	SCD	SCD	SCD	SCD	SCD	SCD	SCD		SCD	SCD			SCD					SCD	SCD	SCD	SCD																										SCD						
INFINITI G37 Sedan	V36	2008 2009 2010	SCD	SCD	SCD	SCD	SCD	SCD	SCD		SCD	SCD			SCD					SCD	SCD	SCD	SCD																												SCD				

Nissan V10.20 Diagnostics List(Note:For reference only)

ILLUSTRATION: S:Sys. Info. C:DTC--Read code & Clear code D:Data Stream

HLL:HEAD LAMP LEVELIZER , LDW:LANE CAMERA , AFS:ADAPTIVE LIGHT , NATS:NATS IMMU , SE:SMART ENTRANCE , AIRL:AIR LEVELIZER , RCM:REARVIEW CAMERA , SCM:S/BLIND CAMERA , AEM:ACTIVE ENG MOUNT , AS:ACTIVE SUS , ASCD:Auto Speed Control Device , CGC:CHG COMM , TETC:TK_ECU_TYPE_CLUCH , DC:DISTANCE CONTROL , MA:MOTOR ASSIST , IVMS:Integrated Voice-Messaging System , TQC:TORQ CONT , AP:ACCELE PEDAL , CON:CONVERTIBLE ROOF

Vehicle	Vehicle Type	Release Date	Eng	AT	ABS	BCM	IPC	ABG	ICC	HVAC	ITM	EPS	IPDM	APM	HLL	E-4WD	I-KEY	DIU	ASD	PSB	ADP	4WD	4WAS /RAS /HICAS	SONAR	LDW	NATS	SE	AIRL	RCM	SCM	AS	MA	IVMS	TCS	AP	ABD	CON	E-SUS	LAS	Break Cont	AUTO SLID	CAN GAT EWA	POP UP HOO	TOTAL ILLU	OCUPA NT	MULTI DISP	SVT				
ROGUE	S35	2007 2008 2009 2010 2011	SC D	SC D	SC D	SC D	CD	SC D				SC D	CD		SC D								SC D																												
SENTRA	B16	2006 2007 2008 2009 2010 2011	SC D	SC D	SC D	SC D	CD	SC D				SC D	CD				SC D																																		
SENTRA	B15	2000 2001 2002 2003 2004 2005 2006*	SC D	SC D	SC D	SC D	CD	SC	SC D	SC D	SC D	SC D	SC D	SC D	SC D	SC D	SC D	SC D	SC D	SC D	SC D	SC D	SC D	CD	SC D																										
SENTRA	B14	1995 1996 1997 1998 1999*	SC D	SC D	SC D	SC D	CD	SC	SC D	SC D	SC D	SC D	SC D	SC D	SC D	SC D	SC D	SC D	SC D	SC D	SC D	SC D	SC D	CD	SC D																										
TITAN	A60	2003 2004 2005 2006 2007 2008 2009 2010 2011	SC D	SC D	SC D	SC D	CD	SC	SC D	SC D	SC D	SC D	SC D	SC D	SC D	SC D	SC D	SC D	SC D	SC D	SC D	SC D	SC D	CD	SC D																										
VERSA Hatch back	C11	2007 2008 2009 2010 2011	SC D	SC D	SC D	SC D	CD	SC				SC D	CD				SC D						SC D																												

Nissan V10.20 Diagnostics List (Note:For reference only)

ILLUSTRATION: S:Sys. Info. C:DTC--Read code & Clear code D:Data Stream

HLL:HEAD LAMP LEVELIZER , LDW:LANE CAMERA , AFS:ADAPTIVE LIGHT , NATS:NATS IMMU , SE:SMART ENTRANCE , AIRL:AIR LEVELIZER , RCM:REARVIEW CAMERA , SCM:S/BLIND CAMERA , AEM:ACTIVE ENG MOUNT , AS:ACTIVE SUS , ASCD:Auto Speed Control Device , CGC:CHG COMM , TETC:TK_ECU_TYPE_CLUCH , DC:DISTANCE CONTROL , MA:MOTOR ASSIST , IVMS:Integrated Voice-Messaging System , TQC:TORQ CONT , AP:ACCELE PEDAL , CON:CONVERTIBLE ROOF

Vehicle	Vehicle Type	Release Date	Eng	AT	ABS	BCM	IPC	ABG	ICC	HVAC	ITM	EPS	IPDM	APM	HLL	E-4WD	I-KEY	DIU	ASD	PSB	ADP	4WD	4WAS /RAS /HICAS	SON AR	LDW	NATS	SE	AIRL	RCM	SCM	AS	MA	IVMS	TCS	AP	ABD	CON	E-SUS	LAS	Brea k Cont	AUT O SLID	CAN GAT EWA	POP UP HOO	TOT AL ILLU	OCC UPA NT	MUL TI DISP	SVT									
CABSTAR	TL0	2003	SD	SD	SD	SD	CD	SC	SD	SD	SD	SD	SD	SD	SD	SD	CD	CD	SD	SD	SD	SD	SD	CD	SD	CD	CD	SD	SD	SD	CD	MA	IVMS	TCS	AP	ABD	CON	E-SUS	LAS	SD																
CABSTAR	F24	2006 2007 2008 2009	SD	SD	SD	SD	CD	SC					SD										CD																																	
CABSTAR E	TL0	1998 2001	SD	SD	SD	SD	CD	SC	SD	SD	SD	SD	SD	SD	SD	SD	CD	CD	SD	SD	SD	SD	SD	CD	SD	CD	CD	SD	SD	SD	CD	MA	IVMS	TCS	AP	ABD	CON	E-SUS	LAS	SD																
INFINITI EX35/EX30d	J50	2009 2010 2011	SD	SD	SD	SD	SD	SD	SD		SD		SD												SD																															
INFINITI EX37	J50	2008 2009	SD	SD	SD	SD	SD	SD	SD		SD		SD	SD	SD																																									
INFINITI FX37/FX50	S51	2008 2009	SD	SD	SD	SD	SD	SD	SD		SD		SD	SD	SD							SD	SD	SD																																
INFINITI FX37/FX50/FX30d	S51	2009 2010	SD	SD	SD	SD	SD	SD	SD		SD		SD	SD	SD										SD																															
INFINITI M37/M56/M30d	Y51	2010 2011	SD	SD	SD	SD	CD	SD	SD	SD	SD		SD	SD	SD																																									
JUKE(2WD)	F15	2010	SD	SD	SD	SD	CD	SD		SD	SD	SD	SD		SD	SD																																								
JUKE(4WD)	F15	2010	SD	SD	SD	SD	CD	SD		SD	SD	SD	SD		SD	SD																																								
MAXIMA	A33	*	SD	SD	SD	SD	CD	SD	SD	SD	SD	SD	SD	SD	SD	SD	CD	CD	SD	SD	SD	SD	SD	CD	SD	CD	CD	SD	SD	SD	CD	MA	IVMS	TCS	AP	ABD	CON	E-SUS	LAS	SD																
MAXIMA	A32	*	SD	SD	SD	SD	CD	SD	SD	SD	SD	SD	SD	SD	SD	SD	CD	CD	SD	SD	SD	SD	SD	CD	SD	CD	CD	SD	SD	SD	CD	MA	IVMS	TCS	AP	ABD	CON	E-SUS	LAS	SD																
MICRA	K13	2010	SD	SD	SD	SD	CD	SD			SD	SD	SD		SD	SD								SD																																

Nissan V10.20 Diagnostics List (Note:For reference only)

ILLUSTRATION: S:Sys. Info. C:DTC--Read code & Clear code D:Data Stream

HLL:HEAD LAMP LEVELIZER , LDW:LANE CAMERA , AFS:ADAPTIVE LIGHT , NATS:NATS IMMU , SE:SMART ENTRANCE , AIRL:AIR LEVELIZER , RCM:REARVIEW CAMERA , SCM:S/BLIND CAMERA , AEM:ACTIVE ENG MOUNT , AS:ACTIVE SUS , ASCD:Auto Speed Control Device , CGC:CHG COMM , TETC:TK_ECU_TYPE_CLUCH , DC:DISTANCE CONTROL , MA:MOTOR ASSIST , IVMS:Integrated Voice-Messaging System , TQC:TORQ CONT , AP:ACCELE PEDAL , CON:CONVERTIBLE ROOF

Vehicle	Vehicle Type	Release Date	Eng	AT	ABS	BCM	IPC	ABG	ICC	HVAC	ITM	EPS	IPDM	APM	HLL	E-4WD	I-KEY	DIU	ASD	PSB	ADP	4WD	4WAS /RAS /HICAS	SONAR	LDW	NATS	SE	AIRL	RCM	SCM	AS	MA	IVMS	TCS	AP	ABD	CON	E-SUS	LAS	Break Cont	AUTO SLID	CAN GAT EWA	POP UP HOO	TOTAL ILLU	OCC UPANT	MULTI DISP	SVT				
PICKUP	D22	1998 1999 2001 2003 2004 2008 2009 2011*	SC D	SC D	SC D	SC D	CD	SC D	SC D	SC D	SC D	SC D	SC D	SC D	SC D	SC D	SC D	CD	SC D	SC D	SC D	SC D	SC D	CD	SC D	C D	CD	SD	SD	SC D	CD	SC D	SC D								SC D										
PRIME RA	P12	*	SC D	SC D	SC D	SC D	CD	SC D	SC D	SC D	SC D	SC D	SC D	SC D	SC D	SC D	SC D	CD	SC D	SC D	SC D	SC D	SC D	CD	SC D	SC D	C D	CD	SD	SD	SC D	CD	SC D	SC D									SC D								
PRIME RA	P11	*	SC D	SC D	SC D	SC D	CD	SC D	SC D	SC D	SC D	SC D	SC D	SC D	SC D	SC D	SC D	CD	SC D	SC D	SC D	SC D	SC D	CD	SC D	SC D	C D	CD	SD	SD	SC D	CD	SC D	SC D									SC D								
QASH QAI	J10	2006 2007 2008 2009 2010	SC D	SC D	SC D	SC D	CD	SC D			SC D	SC D	CD		SC D	SC D																																			
Qashqai+2	J10	2008 2010	SC D	SC D	SC D	SC D	CD	SC D			SC D	SC D	CD		SC D	SC D							SC D																												
SKYLINE	R34	*	SC D	SC D	SC D	SC D	CD	SC D	SC D	SC D	SC D	SC D	SC D	SC D	SC D	SC D	SC D	CD	SC D	SC D	SC D	SC D	SC D	CD	SC D	SC D	C D	CD	SD	SD	SC D	CD	SC D	SC D										SC D							
SUNNY	Y10	*	SC D	SC D	SC D	SC D	CD	SC D	SC D	SC D	SC D	SC D	SC D	SC D	SC D	SC D	SC D	CD	SC D	SC D	SC D	SC D	SC D	CD	SC D	SC D	C D	CD	SD	SD	SC D	CD	SC D	SC D										SC D							
TEANA	J32	2008 2009 2010 2011	SC D	SC D	SC D	SC D	CD	SC D		SC D	SC D		SC D																																		SC D				
TEANA	J31	2003 2004 2005 2006 2007	SC D	SC D	SC D	SC D	CD	SC D	SC D	SC D	SC D	SC D	SC D	SC D	SC D	SC D	SC D	CD	SC D	SC D	SC D	SC D	SC D	CD	SC D	SC D	C D	CD	SD	SD	SC D	CD	SC D	SC D													SC D				
TERRANO	R20	*	SC D	SC D	SC D	SC D	CD	SC D	SC D	SC D	SC D	SC D	SC D	SC D	SC D	SC D	SC D	CD	SC D	SC D	SC D	SC D	SC D	CD	SC D	SC D	C D	CD	SD	SD	SC D	CD	SC D	SC D													SC D				
TIIDA Hatchback	C11	2005 2006 2007 2008 2009 2010	SC D	SC D	SC D	SC D	CD	SC D			SC D	SC D	CD		SC D	SC D	SC D																														SC D				

Nissan V10.20 Diagnostics List (Note:For reference only)

ILLUSTRATION: S:Sys. Info. C:DTC--Read code & Clear code D:Data Stream

HLL:HEAD LAMP LEVELIZER , LDW:LANE CAMERA , AFS:ADAPTIVE LIGHT , NATS:NATS IMMUN , SE:SMART ENTRANCE , AIRL:AIR LEVELIZER , RCM:REARVIEW CAMERA , SCM:S/BLIND CAMERA , AEM:ACTIVE ENG MOUNT , AS:ACTIVE SUS , ASCD:Auto Speed Control Device , CGC:CHG COMM , TETC:TK_ECU_TYPE_CLUCH , DC:DISTANCE CONTROL , MA:MOTOR ASSIST , IVMS:Integrated Voice-Messaging System , TQC:TORQ CONT , AP:ACCELE PEDAL , CON:CONVERTIBLE ROOF

Vehicle	Vehicle Type	Release Date	Eng	AT	ABS	BCM	IPC	ABG	ICC	HVAC	ITM	EPS	IPDM	APM	HLL	E-4WD	I-KEY	DIU	ASD	PSB	ADP	4WD	4WAS/RAS/HICAS	SONAR	LDW	NATS	SE	AIRL	RCM	SCM	AS	MA	IVMS	TCS	AP	ABD	CON	E-SUS	LAS	Break Cont	AUTO SLID	CAN GAT EWA	POP UP HOO	TOTAL ILLU	OCC UPAN	MULTI DISP	SVT	
CEDRIC	Y31	1995 1996 1998 1999 2004 2005 2007 2009 2010	SC D	SC D	SC D	SC D	CD	SC	SC	SC	SC	SC	SC	SC	SC	SC	SC	CD	SC	SC	SC	SC	SC	CD	SC	SC	C	CD	SD	SD	SC	MA	SC	SC												SC D		
CEDRIC/GLO RIA	Y34	*	SC D	SC D	SC D	SC D	CD	SC	SC	SC	SC	SC	SC	SC	SC	SC	SC	CD	SC	SC	SC	SC	SC	CD	SC	SC	C	CD	SD	SD	SC	MA	SC	SC													SC D	
CEDRIC/GLO RIA	Y33	*	SC D	SC D	SC D	SC D	CD	SC	SC	SC	SC	SC	SC	SC	SC	SC	SC	CD	SC	SC	SC	SC	SC	CD	SC	SC	C	CD	SD	SD	SC	MA	SC	SC													SC D	
CIMA	FY33	*	SC D	SC D	SC D	SC D	CD	SC	SC	SC	SC	SC	SC	SC	SC	SC	SC	CD	SC	SC	SC	SC	SC	CD	SC	SC	C	CD	SD	SD	SC	MA	SC	SC													SC D	
CREW	K30	1996 1998 1999 2002 2005 2007	SC D	SC D	SC D	SC D	CD	SC	SC	SC	SC	SC	SC	SC	SC	SC	SC	CD	SC	SC	SC	SC	SC	CD	SC	SC	C	CD	SD	SD	SC	MA	SC	SC													SC D	
DATS UN TRACK	D22	*	SC D	SC D	SC D	SC D	CD	SC	SC	SC	SC	SC	SC	SC	SC	SC	SC	CD	SC	SC	SC	SC	SC	CD	SC	SC	C	CD	SD	SD	SC	MA	SC	SC													SC D	
DUALI S	J10	2007 2009 2010	SC D	SC D	SC D	SC D	CD	SC		SC	SC	SC	SC	SC	SC	SC							SC																									SC D
ELGRAND	E52	2010 2011	SC D	SC D	SC D	SC D	CD	SC	SC	SC	SC	SC	SC	SC	SC	SC			SC	SC	SC	SC	SC	CD													SC	SC										SC D
ELGRAND	E51	2002 2003 2004 2005 2006 2007 2008 2009	SC D	SC D	SC D	SC D	CD	SC	SC	SC	SC	SC	SC	SC	SC	SC	SC	CD	SC	SC	SC	SC	SC	CD	SC	SC	C	CD	SD	SD	SC	MA	SC	SC														SC D

Nissan V10.20 Diagnostics List (Note: For reference only)

ILLUSTRATION: S:Sys. Info C:DTC--Read code & Clear code D:Data Stream

HLL:HEAD LAMP LEVELIZER , LDW:LANE CAMERA , AFS:ADAPTIVE LIGHT , NATS:NATS IMMU , SE:SMART ENTRANCE , AIRL:AIR LEVELIZER , RCM:REARVIEW CAMERA , SCM:S/BLIND CAMERA , AEM:ACTIVE ENG MOUNT , AS:ACTIVE SUS , ASCD:Auto Speed Control Device , CGC:CHG COMM , TETC:TK_ECU_TYPE_CLUCH , DC:DISTANCE CONTROL , MA:MOTOR ASSIST , IVMS:Integrated Voice-Messaging System , TQC:TORQ CONT , AP:ACCELE PEDAL , CON:CONVERTIBLE ROOF

Vehicle	Vehicle Type	Release Date	Eng	AT	ABS	BCM	IPC	ABG	ICC	HVAC	ITM	EPS	IPDM	APM	HLL	E-4WD	I-KEY	DIU	ASD	PSB	ADP	4WD	4WAS/RAS/HICAS	SONAR	LDW	NATS	SE	AIRL	RCM	SCM	AS	MA	IVMS	TCS	AP	ABD	CON	E-SUS	LAS	Break Cont	AUTO SLID	CAN GAT EWA	POP UP HOO	TOTAL ILLU	OCC UPNT	MULTI DISP	SVT									
NAVARA(TH I)	D40	2007 2009	SCD	SCD	SCD	SCD	CD	SCD	SCD				CD		SCD		SCD				SCD	SCD	CD																																	
PICKUP/NAVARA	D22	1997 2008 2009 2011	SCD	SCD	SCD	SCD	CD	SCD	SCD	SCD	SCD	SCD	SCD	SCD	SCD	SCD	SCD	CD		SCD	SCD	SCD	SCD	CD	SCD	SCD	C	CD	SD	SD																			SCD							
PULSAR	N16	2000	SCD	SCD	SCD	SCD	CD	SCD	SCD	SCD	SCD	SCD	SCD	SCD	SCD	SCD	SCD	CD		SCD	SCD	SCD	SCD	CD	SCD	SCD	C	CD	SD	SD																				SCD						
PULSAR WAGON	Y11	*	SCD	SCD	SCD	SCD	CD	SCD	SCD	SCD	SCD	SCD	SCD	SCD	SCD	SCD	SCD	CD		SCD	SCD	SCD	SCD	CD	SCD	SCD	C	CD	SD	SD																					SCD					
MAXIMA/CEFIRO	J32	2008 2009 2011	SCD	SCD	SCD	SCD	CD	SCD		SCD	SCD		SCD									SCD																															SCD			
SUNNY/ALMERA	N16	*	SCD	SCD	SCD	SCD	CD	SCD	SCD	SCD	SCD	SCD	SCD	SCD	SCD	SCD	SCD	CD		SCD	SCD	SCD	SCD	CD	SCD	SCD	C	CD	SD	SD																							SCD			
SUNNY/ALMERA	N15	*	SCD	SCD	SCD	SCD	CD	SCD	SCD	SCD	SCD	SCD	SCD	SCD	SCD	SCD	SCD	CD		SCD	SCD	SCD	SCD	CD	SCD	SCD	C	CD	SD	SD																									SCD	