

## SPRINTER **V11.20** Diagnostics List (Note:For reference only )

Menu		Functions			
Model	System	Sys. Info.	Read code	Clear code	Data stream
	ME-Motor electronics	√	√	√	√
	CR-common rail	√	√	√	√
	KI-Instrument cluster	√	√	√	√
	WSP-Immobilizer	√	√	√	√
	ABW-Airbag with widow bag	√	√	√	
	ABS-Anti-lock braking system	√	√	√	√
	AB-Airbag	√	√	√	
	EWM-electronic selector lever module	√	√	√	√
	EGS-electronic transmission control	√	√	√	√
	EDW2-anti-theft alarm2	√	√	√	√
	HZR-heating control	√	√	√	√
	ZV-central locking system	√	√	√	√
	WSP-immobilizer	√	√	√	√
901.6 902.6 903.6	CR-common rail	√	√	√	√
904.6 905.6 690.6	KI-instrument cluster	√	√	√	√
	SSG-Sprintshift transmission	√	√	√	√
	ME-motor electronics	√	√	√	√
	NGT_ME	√	√	√	√
	RFH-backup assist	√	√	√	√
	ARS-All-wheel system	√	√	√	√
	CDI-Common Rail Diesel Injection	√	√	√	√
	ABS-Anti-lock braking system	√	√	√	√
	ABW-Airbag with widow bag	√	√	√	√
	LPG-Liquified Petroleum Gas	√	√	√	√
	APS-Auto pilot system	√	√	√	√

## SPRINTER V11.20 Diagnostics List (Note:For reference only )

Menu		Functions				
Model	System	Sys. Info.	Read code	Clear code	Data stream	
Sprinter	ESP-Electronic stability program	√	√	√	√	
	ZHE-heater booster	√		√	√	
	ZHEL	√		√	√	
	906	CDI4_906	√	√	√	√
		CDI3_906	√	√	√	√
		CDID2_906	√	√	√	√
		CDI6_906	√	√	√	√
		CDI60_906	√	√	√	√
		ETC_906	√	√	√	√
		EWM_906	√	√	√	√
		ESP_906	√	√	√	√
		AAG_906	√	√	√	√
		DBE_906	√	√	√	√
		EIS_906	√	√	√	√
		LWR_906	√	√	√	√
		MRM_906	√	√	√	√
		OBF_906	√	√	√	√
		OBF2_906	√	√	√	√
		SAM_906	√	√	√	√
		SRS_906	√	√	√	√
		SRS-L_906	√	√	√	√
		KI_906	√	√	√	√
		TSG_906	√	√	√	√
		KLA_906	√	√	√	√
		PTC_906	√	√	√	√

## SPRINTER V11.20 Diagnostics List (Note:For reference only )

Menu		Functions				
Model	System	Sys. Info.	Read code	Clear code	Data stream	
	ZHE_906	√	√	√	√	
	PTS_906	√	√	√	√	
	VG_906	√	√	√	√	
	ME_906	√	√	√	√	
	STL_906	√	√	√	√	
	STR_906	√	√	√	√	
	FSCU_906	√	√	√	√	
	RDK(As of 2011)_906	√	√	√	√	
	RDK(Up to 2010)_906	√	√	√	√	
	KE_906	√	√	√	√	
	PSM_906	√	√	√	√	
	SCR-Control unit AdBlue	√	√	√	√	
	ENR-Electronic level control	√	√	√	√	
	ESP9-Electronic Stability Program9	√	√	√	√	
Vaneo	Drive	CDI-Common Rail Diesel Injection	√	√	√	
		ECM-Engine Control module	√	√	√	
		ACS-Automatic clutch system	√	√	√	
		FTC-Front transmission control	√	√	√	
		ESM-Electronic selector module	√	√	√	
	Chassis	ESP-Electronic stability program	√	√	√	√
	Body	AB-Airbag	√	√	√	√
		ATA - Anti-theft alarm system	√	√	√	√
		DAS-Drive authorization system	√	√	√	√
	Seat and doors	CL-Central locking	√	√	√	√
Klimatrac	STH-Stationary heater/Heater booster					

## SPRINTER V11.20 Diagnostics List (Note:For reference only )

Menu		Functions				
Model	System	Sys. Info.	Read code	Clear code	Data stream	
	Information and communication	TAC-Automatic temperature	√	√	√	√
		IC-Instrument cluster	√	√	√	√
		PTS-Parktronic system	√	√	√	
Vito/V-class Model designation 638	Vito/V - Class (OBDII)	ME2	√	√	√	
		V6	√	√	√	
		AGN-Electronic level control	√	√	√	
		CDI-Common Rail Diesel Injection	√	√	√	√
		KR-Cigar lighter relay	√	√	√	√
		HZR-heating control	√		√	√
		ABS-Anti-lock braking system	√	√	√	
		AB-Airbag	√	√	√	
		ZHZ-Heater booster	√		√	√
		KI-instrument cluster	√	√	√	
		WSP-immobilizer	√	√	√	√
		ATA - Anti-theft alarm system	√	√	√	√
		CDI3-4 Cylinder	√	√	√	√
		CDI4-4 Cylinder	√	√	√	√
		CDI4-6 Cylinder	√	√	√	√
		ETC-Electronic transmission control	√	√	√	√
		ME-SFI - Motor electronics	√	√	√	√
		ESP-Electronic stability program	√	√	√	√
		EIS-Electronic ignition switch	√	√	√	√
		UCP-Upper control panel	√	√	√	√

## SPRINTER V11.20 Diagnostics List (Note:For reference only )

Menu		Functions			
Model	System	Sys. Info.	Read code	Clear code	Data stream
VITO/VIANO (OBDII)	SAM-Signal acquisition and actuation module	√	√	√	√
	SRS-Supplemental restraint system	√	√	√	√
	IC-Instrument cluster	√	√	√	√
	ESA passenger- Electric seat adjustment passenger	√	√	√	√
	ESA driver- Electric seat adjustment driver	√	√	√	√
	ESD [STE]-L -Left electric sliding door	√	√	√	√
	ESD [STE]-R -Right electric sliding door	√	√	√	√
	SDE-H - Rear sliding/tilting sunroof unit	√	√	√	√
	TPC-Tire pressure monitor	√	√	√	√
	OCP-Overhead control panel	√	√	√	√
	DCM-FL - Door control module front left	√	√	√	√
	DCM-FR - Door control module front right	√	√	√	√
	PTS-Parktronic system	√	√	√	√
	ENR - Electronic level control	√	√	√	√
	ESM-Electronic selector module	√	√	√	√
	AAG Trailer connection unit	√	√	√	√
	PTC - Electric heater control	√	√	√	√
	REAR AC-Rear air conditioning/Rear heater	√	√	√	√

## SPRINTER V11.20 Diagnostics List (Note:For reference only )

Menu		Functions			
Model	System	Sys. Info.	Read code	Clear code	Data stream
Vito/VIANO Model designation 639 (OBDII)	AAC-Automatic air condition/automatic temperature control/heating-ventilation	√	√	√	√
	CDI-Common Rail	√	√	√	√
	ME-SFI-Motor electronics	√	√	√	√
	ETC-Electronic transmission control	√	√	√	√
	ESP-Electronic stability program	√	√	√	√
	TPC-Tire pressure monitor	√	√	√	√
	EIS - Electronic ignition switch	√	√	√	√
	UCP-Upper control panel	√	√	√	√
	SAM - Signal acquisition and actuation module	√	√	√	√
	SRS - Supplemental restraint system	√	√	√	√
	IC - Instrument cluster	√	√	√	√
	COMMANDED	√	√	√	√
	PTS-Parktronic system	√	√	√	√
	DCM-FL - Door control module front left	√	√	√	√
	DCM-FR - Door control module front right	√	√	√	√
VITO/VIANO (CAN BUSII)	AAC-Automatic air condition/automatic temperature control/heating-ventilation	√	√	√	√
	PTC - Electric heater control	√	√	√	√

## SPRINTER **V11.20** Diagnostics List (Note:For reference only )

Menu		Functions			
Model	System	Sys. Info.	Read code	Clear code	Data stream
	ENR - Electronic level control	√	√	√	√
	SDE-H - Rear sliding/tilting sunroof unit	√	√	√	√
	ESA passenger- Electric seat adjustment passenger	√	√	√	√
	ESA driver- Electric seat adjustment driver	√	√	√	√
	ESD [STE]-L -Left electric sliding door	√	√	√	√
	STH-Stationary heater/Heater booster	√	√	√	√
	PSM Parameterizable special module	√	√	√	√
	AAG Trailer connection unit	√	√	√	√
	LWR Headlamp range adjustment	√	√	√	√
	ESD [STE]-R -Right electric sliding door	√	√	√	√

<b>RESET Function</b>					
Vehicle	Year	OIL	BREAK	SAS	ETC
SPRINTER III 906/900	2006 - 2014	√			
VITO 639	2004 - 2014	√			
VIANO 639	2004 - 2014	√			
V/VITO 638(OBDII)	1995 - 2003	√			
V/VITO 638(38-PIN)	1995 - 2003	√			
VANEO 414	2002 - 2005	√			
SPRINTER II 90x.6	2000 - 2006	√			

