



HINO V12.0

1. X : means the function is supported.

2. * : means the function is added or developed newly in the new version

VEHICLE INFORMATION	FUNCTION					
	System	ECU INFO	DTC	DTC Freeze	Data List	Actuations
Engine System	X	X		X	X	Read and Write Injector code Cruise Set Change Speed Limit Setting Change EGR Check DPR Manual Forced Regeneration Reset All Dpr Items
Suspension System	X	X				
Vehicle Stability Control System	X	X		X	X	
Battery	X	X		X		
Hybrid Power	X	X		X	X	
Inverter	X	X		X		
Safety Air Bag		X				
Transmission Case	X	X		X	X	
Transmission Case	X	X				
Bcu (Burner)	X	X		X	X	
Dcu (Urea Scr)	X	X		X	X	
Meter	X	X		X		