

1. X : means the function is supported.

2. * : means the function is added or developed newly in the new version

VEHICLE INFORMATION		FUNCTION					
MODULE	System	ECU INFO	DTC	DTC Freeze	Data List	Actuations	Spec. Func.
Engine	Navistar Diesel Engine	X	X		X		
Transmission	Allison Transmission	X	X		X		
Brake	Bendix Brake System	X	X		X		
Brake	Meritor Wabco Brake System	X	X		X		